

1.

Remove the protective wrap.




2.

Download the Ring app.




3.

Scan the QR code on your device.



4.


Follow in-app setup.



Installation

1.


Choose a location near a source of possible flooding or freezing.



2.

Place your sensor on a level surface with the Ring logo facing up.

NOTE: For best results, position the sensor at the lowest point of the area you want to monitor, where it won't be accidentally kicked or moved.



Amazon Sidewalk-enabled device; requires Amazon Sidewalk coverage for use. Coverage may vary by location. For Amazon Sidewalk information, visit ring.com/sidewalk



ring.com/contact



ring.com/help