

# Quick Start

## 1. Download the Ring app.

The Ring app walks you through setting up and managing your Wall Light Solar.

## 2. Set up and install your Ring Bridge.

Your Bridge connects your Wall Light Solar to the Ring app.

## 3. Open the Ring app and tap Set Up a Device.

Select **Smart Lighting** and scan this QR code. Then, just follow the in-app instructions to install and set up this device.




QR+FR




For additional help, visit:  
[ring.com/help](https://ring.com/help)

# Installation



## Wall Anchors

Use if installing on brick or stucco.



## USB Charging Cable

Use this to charge your Wall Light before you install it.  
When the lights stop flashing and remain on, your Wall Light is ready to install.